


Technical Description and Operating Instructions



Aureol® Fidelity

In-Ear Earphones

Teufel

Contents

| | |
|---|----------|
| General notes and information | 3 |
| Notice | 3 |
| Original packaging..... | 3 |
| Complaints..... | 3 |
| Contact | 3 |
| Proper use..... | 4 |
| Product contents | 4 |
| Safety notes | 5 |
| Connecting the in-ear earphones..... | 6 |
| Handling..... | 6 |
| Replacing the ear pieces..... | 7 |
| Fastening clip | 7 |
| Cleaning | 7 |
| Disposing of the device | 8 |
| Technical data | 8 |

General notes and information

Notice

The information in this document may change without prior notice and in no way constitutes any liability on the part of Lautsprecher Teufel GmbH.

No part of these instructions may be reproduced in any form or be broadcasted in any way electronically, mechanically, by photocopy or recording without the written permission of Lautsprecher Teufel GmbH.

© Lautsprecher Teufel GmbH
Version 1.0
January 2012

Original packaging

If you wish to exercise your eight-week right of return, we ask that you be absolutely sure to hold onto the packaging. We can only accept the return of the speakers WITH THE ORIGINAL PACKAGING.

Empty boxes are not available!

Complaints

In case of complaint we will need the following information to process your enquiry:

1. Invoice number

Can be found on the sales slip (enclosed with the product) or on the order confirmation received as a PDF document, e.g. 4322543

2. Serial number or batch number

Located on the packaging of the product,
e.g. serial number: UL 04007480121A

Many thanks for your support!

Contact

For questions, suggestions or criticism, please contact our customer service department:

Lautsprecher Teufel GmbH
Gewerbehof Buelowbogen
Buelowstrasse 66
10783 Berlin (Germany)

Phone 00800 - 200 300 40 (free of charge)

Fax: +49 (0)30 / 300 930 930

E-mail: servcie@teufelaudio.com

www.teufelaudio.com

Proper use

Only use the in-ear earphones as described in these operating instructions. Any other use will be deemed as not in accordance with the instructions and may lead to damage to property or even persons.

The manufacturer accepts no liability for damage caused by use not in accordance with the instructions.


The in-ear earphones are intended for private use.



Before operating the in-ear earphones, please read the safety notes and operating instructions carefully. This is the only way to use all functions safely and reliably.

Keep the operating instructions safe and pass them on to anyone who may own the unit after you.

Product contents



Safety notes

Danger**Danger of suffocation for children!**

Children could swallow small parts and suffocate as a result.

- Make sure that children do not remove any small parts from the in-ear earphones or play with them.
-

**Danger to hearing!**

Excessive sound pressure may cause the loss of the hearing sense if earphones are used.

- Avoid steady hearing with high volumes via in-ear earphones.
 - In-ear earphones must only be connected to headphone outputs! Do not connect them to the speaker output of an amplifier.
 - Set the volume control of your audio source to low level before you insert the in-ear earphones into your ears.
-

Danger**Danger in road traffic!**

In-ear earphones considerably muffle exterior sounds.

- Therefore, do not use in-ear earphones when driving vehicles or cycling due to reasons of road safety.
-

Danger**Risk of injury!**

Insufficiently fixed ear pieces may become lodged in the ear.


- Attach ear pieces firmly to the headphones when changing them.
 - If an ear piece is lodged in your auditory canal and you are unable to remove it yourself, consult an ear, nose and throat specialist.
 - Do not use your earphones in areas where there is a risk of explosion.
-

Danger**Risk of damage!**


Extreme temperatures and rude handling may damage the earphones.

- Keep your earphones away from wet conditions, moisture and heat (e.g. in your car in the summer) and mechanical stress (e.g. severe shocks, pressure and being dropped).
 - Remove the earphones before using hair spray.
 - Do not remove the earphones by pulling on the cable.
-

Connecting the in-ear earphones




Insert the 3.5 mm phone jack of the earphones into the headphones connection jack of your audio source.



If necessary, use one of the enclosed adapters.

Handling




1. Your in-ear earphones are marked with **L** (left ear) and **R** (right ear). Take hold of the earphones according to the labelling and as shown above.

2. Insert the earphones into the auditory canals with the cables pointing downwards. The earphones must have a tight fit and fill the ear well. If this is not the case and if the ear pieces are too big or too small, replace them with another pair from the product contents.
3. When removing the earphones, do not pull on the cable, but take hold of the earphone housing. Then twist and pull them out of your ears.

Replacing the ear pieces


The earphones must have a good and tight ear-fit. Otherwise, deep bass sounds will be barely audible.

Additional ear pieces for different ear sizes are included in the product contents. Choose the ear pieces which are perfect for you and attach them to the earphones.



When you replace the ear pieces, be sure to firmly attach them to the earphones to prevent them from detaching and becoming lodged in your ear.

Fastening clip



Use the enclosed fastening clip to secure the cable on your clothing.

Cleaning

The sound channels of the earphones may clog with cerumen (earwax). Therefore, clean the ear pieces regularly. Clogged earphones do not only sound quieter and worse, but they can also be damaged due to possible overload by readjusting the volume!

Remove the ear pieces from the earphones. Only clean the ear pieces with warm water and without any rinsing and cleaning agents or solvents.

Disposing of the device



Used units must not be disposed of with household waste.

If the unit is no longer operational, every consumer is required by law to dispose of used devices separately from household waste, e.g. at a collection point run by the communal au-

thority borough. In this way it is ensured, that used devices are properly recycled and that negative consequences on the environment are avoided.

For this reason, electrical equipment is labelled with the displayed symbol.

Technical data

Cable length: 1.2 m
Weight: 14.5 g

You can find further technical data in the product description on our website at www.teufelaudio.com.

Technical changes reserved!

Teufel

For questions, suggestions or criticism please contact our customer service department:

Lautsprecher Teufel GmbH
Gewerbehof Buelowbogen - Aufgang D1
Buelowstrasse 66
10783 Berlin (Germany)
Phone 00800 - 200 300 40 (free of charge)

Fax: +49 (0)30 / 300 930 930
E-mail: service@teufelaudio.com
www.teufelaudio.com

No responsibility is assumed for the correctness of this information.
Technical changes, typographical errors and other errors reserved.