


Technical Description and Operating Instructions



iTeufel Move

Inear Headset



Teufel

Contents

General Notes and Information.....	3	Connecting the Earphones.....	7
Notice.....	3	Handling.....	8
Contact.....	3	Remote Control.....	9
Complaints.....	3	Changing the Eartips.....	10
Warranty conditions.....	3	Cleaning.....	11
Returns.....	4	Technical data.....	11
Protecting the environment.....	4		
Product contents.....	4		
For Your Safety.....	5		
Please read.....	5		
Proper use.....	5		
Definition of terms.....	5		
Safety Notes.....	6		

General Notes and Information

Notice

The information in this document may be changed without prior notice and in no way constitutes any liability on the part of Lautsprecher Teufel GmbH.

No part of these instructions may be reproduced in any form or be broadcasted in any way electronically, mechanically, by photocopy or recording without the written permission of Lautsprecher Teufel GmbH.

© Lautsprecher Teufel GmbH

Version 1.0

February 2015

Contact

For questions, suggestions or criticism please contact our customer service department:

Lautsprecher Teufel GmbH

BIKINI Berlin

Budapester Strasse 44

10787 Berlin (Germany)

Phone 00800 - 200 300 40 (toll-free)

Fax +49 (0)30 / 300 930 930

E-Mail: service@teufelaudio.com

www.teufelaudio.com

Complaints

In case of complaint we will need the following information to process your enquiry:

1. Invoice number

Can be found on the sales slip (enclosed with the product) or on the order confirmation received as a PDF document, e. g. 4322543

2. Serial number and/or batch number

Located on the device packaging, e. g. serial number: UL 04007480121A

Many thanks for your support!

Warranty conditions

12 year warranty for loudspeakers from date of purchase. Covers materials and workmanship, excludes damage caused by improper use or electrical or mechanical overload. Proof of warranty is the original of our invoice. This warranty applies solely to loudspeakers, amplifiers and electronics purchased from Teufel by an end user for private use. The warranty is not valid for loudspeakers, amplifiers and electronics, which pass to an end user via a third party merchant. In the case of a private re-sale of Teufel products the warranty may be transferred to the purchaser as long as the original proof of purchase is also passed on to the purchaser.

Returns

Lautsprecher Teufel provides the right to exchange or return within eight weeks with refund of the purchase price paid.

Return of individual components sold as a package is only possible if these components are also sold individually by Lautsprecher Teufel. In the case of the return of one or more individual components the package price reduction offered by Lautsprecher Teufel on all components in a package no longer applies. The amount refunded to the customer for the components returned will therefore only be the difference between the package price and the purchase price of the individual parts. The economic result for the customer is that it is as if he/she had originally bought the remaining components at their individual prices.

Further information on the subject of returns may be found on the back of the returns form enclosed with the order or online in the support area of our website www.teufelaudio.com.

If you need to return your goods please do not act without first speaking to Lautsprecher Teufel.

We can only process or accept your returns if you give us prior notification by telephone and discuss how to proceed!

Protecting the environment



Used units must not be disposed of with household waste!

■ If the unit is no longer operational, every consumer is required by law to dispose of used devices separate from household waste, e. g. at a collection point run by the communal authority borough. In this way, used devices can be recycled and waste materials disposed of in an environmentally friendly manner.

For this reason, electrical equipment is labelled with the displayed symbol.

Product contents

- 1 headset iTeufel Move
- 1 pouch
- 3 pair of ear tips
- 1 transport tube
- 1 adapter 3 x 3.5 mm

For Your Safety

Please read



Before you use the earphones, please carefully read through the safety notes and operating instructions. Only in this manner, can all functions be used safely and reliably.

Keep the operating instructions safe and pass them on to anyone who may own the unit after you.

Proper use

The earphones are designed for the playback of music and speech from an external player. Only use the earphones as described in this instruction manual. Any other use will be deemed as not in accordance with the instructions and may lead to damage of property or even persons.

The manufacturer cannot be held liable for damages caused by improper use. The earphones are intended for private use.

Definition of terms

You can find the following signal terms in these instructions:

WARNING

This signal term indicates a moderate risk, which, if not avoided, may result in death or severe injury.

CAUTION

This signal term indicates a low risk, which, if not avoided, may result in minor or moderate injury.

NOTICE

This signal term warns you of potential damage.

Safety Notes

This chapter provides general safety information that should be considered for your own protection and that of others. Please note that additional warnings are listed in the individual chapters as necessary.

Danger of suffocation for children!

Make sure that children do not remove any small parts from the earphones. They could swallow and choke on them.



Extended listening at high volumes may lead to hearing loss.

To avoid damage to health, avoid extended listening at high volumes.

Inear headphones may only be connected to earphone jacks! Do not connect them to the speaker jack of an amplifier.

Set the volume control of your audio source to low level before you insert the inear headphones in your ears.

Risk of road traffic accidents!

Inear headphones suppress outside noise to a considerable degree. For the purpose of road safety, do not wear inear headphones when driving passenger vehicles or when cycling.

When wearing the inear headphones, pay special attention to your surroundings, especially when crossing streets.

Risk of injury!

When you replace the ear tips, be sure to firmly attach them to the ear phones to prevent them from detaching and becoming lodged in your ear.

If an ear tip is lodged in your auditory canal and you are unable to remove it yourself, consult an ear, nose and throat specialist.

Do not use your headphones in areas where there is a risk of explosion.

Risk of damage!

Keep your headphones away from wet conditions, moisture and heat (e. g. in your car in the summer) and mechanical stress (e. g. severe shocks, pressure and being dropped).

Remove the headphones before using hair spray.

Do not remove the headphones by pulling on the cable.

Connecting the Earphones


- Plug the headphone jack into the headphones port of your audio device.

CAUTION



Extended listening at high volumes may lead to hearing loss.

- *To avoid damage to health, avoid extended listening at high volumes.*
- *Inear headphones may only be connected to earphone jacks! Do not connect them to the speaker jack of an amplifier.*
- *Set the volume control of your audio source to low level before you insert the inear headphones in your ears.*




Handling

Your Inear Headset is marked with an L (for the left ear) and an R (for the right ear).

Take the headphones in your hands as shown in the diagram to the right.

Place the earbuds, with the cable towards the ground, into your ears. They should fit snug and be well-sealed within the ear canal.

Should this not be the case and the eartips are either too big or too small, replace them with another pair of the enclosed eartips.




NOTICE

Do not remove the headphones by pulling on the cable, instead pull gently on each earbud.

Remote Control


On the cable for the left ear is a remote control with 3 buttons, with which you can control different functions on your iPhone (see the table below).



	Push	Button		
		a	b	c
Play mode	1 x	Volume up	Play / Pause	Volume down
	2 x		Next song	
	3 x		Previous song	
	long		Siri	
Phone mode	1 x	Volume up	Receiving a call or hang up	Volume down
	2 x		Rejecting a call	

Changing the Eartips

If the eartips do not fit correctly, it will be hard to hear deep bass. Because all ears are different, we have included different sizes of eartips with the headphones. Find the optimal eartip size and put them onto the earbuds.



⚠ CAUTION


Make sure that the eartips are placed securely on the earbuds so they do not fall off or get stuck in your ear.

See an ear, nose and throat specialist if an eartip becomes lodged in the ear canal and you are unable to remove it.

Cleaning

Under no circumstances should aggressive cleaning products be used. They can damage the sensitive parts.

Place the eartips to be cleaned in the transport tube and fill it halfway with water. Then, simply shake well to clean.



Technical data

Frequency range	20 Hz - 20 kHz
Cable length	1,12 m
Net. weight:	0,15 kg

You can find further technical data on our website.
Technical changes reserved!



This product confirms with Council of the European Union guideline 2011/65/EU (RoHS).

Teufel

For questions, suggestions or criticism please contact our customer service department:

Lautsprecher Teufel GmbH
BIKINI Berlin
Budapester Strasse 44
10787 Berlin (Germany)

Phone: 00800 - 200 300 40 (toll-free)
Fax: +49 (0)30 - 300 930 930
www.teufelaudio.com

No responsibility is assumed for the correctness of this information.
Technical changes, typographical errors and other errors reserved. Instruction