



Teufel Connector

QUICK START GUIDE

UNBOXING

Welcome to Teufel Streaming


1. Take a moment to ensure that all of the components listed below were included in delivery.
2. Before beginning setup or use of your new Teufel Streaming device, please read the Safety Notes included with the device.



Please keep the box for the duration of the warranty period.

READY YOUR WI-FI


1. Make sure that your Wi-Fi router has been activated, is using the latest software and has access to the internet.
2. The router should be placed in a central location so that it can supply your entire household with a sufficient Wi-Fi signal.



During the setup process, it is important to ensure that all Teufel Streaming devices receive a sufficient Wi-Fi signal. A signal that is too weak can lead to dropped connections.

SETUP

1. Use the included RCA cable or a TOSLINK optical cable to connect the Teufel Connector to your stereo system. The RCA cable must be connected to the terminal marked “OUT.”





2. Connect your Connector device to a power source.



When playing back audio from hi-res files, we recommend a wired network connection via Ethernet cable.

GETTING STARTED

1. Check that your smart device is connected to your home Wi-Fi.
2. Download the “Teufel Raumfeld” App from the Play Store/App Store.
3. Locate your Wi-Fi password and keep it close at hand.
4. After starting the app, follow the directions step-by-step until the setup process is complete.



Note regarding the integration of additional devices to an existing Teufel Streaming system:

It is not necessary to carry out the entire setup process again.

You can add additional devices via the “Settings” option in the app.

TROUBLESHOOTING

The LEDs don't light up.

Please make sure that the device is connected to a power supply. Check that the power cord is properly plugged into the power jack on your Teufel Streaming device.

After setup, my Teufel Streaming devices no longer, or only sporadically, connect to the Wi-Fi.

Make sure that the Teufel Streaming devices and the smart device with the Teufel Raumfeld App are using the same Wi-Fi. If your router offers guest access, this should not be used for your Teufel Streaming system. Check that the Dynamic Host Configuration Protocol (DHCP) on your home router is activated and that all essential devices within the home network are able to communicate with each other.

The Teufel Streaming devices are connected to the network but playback is interrupted or skips.

It is possible that one or more Teufel Streaming devices are receiving either too little or, at times, even no Wi-Fi signal. Try placing the device closer to the router, experiment with different placement locations or create a wired connection between the affected device and router via Ethernet cable. If possible, try streaming lower resolution audio files.

Where can I find additional information and help?

In case of unexpected problems or additional questions, you'll find an extended FAQ section in the Teufel Streaming Online Manual at manual.teufel.de.





Contact

If you have any product related questions, need product support or have suggestions, please contact us at:

Great Britain:

+44 33 08 08 04 89

Other countries:

00800 200 300 40

Online support: <http://manual.teufelaudio.com>

Contact form: www.teufelaudio.com/contact

Lautsprecher Teufel GmbH

Bikini Berlin

Budapester Str. 44, 10787 Berlin – Germany

www.teufel.de